



Measure width of nose.

Nasal Mask Measurement

- Using the ruler above measure the width of your nose.
- Using your nose measurement, find your mask size in one of the charts below.

Size	*Advance
Small	
Advance	

* SleepWeaver Advance is one size fits most. If your nose measurement falls under 1 1/4 inches try SleepWeaver Advance Small first.

Size	Élan®
Small	
Regular	
Large	



CPAPMAN.COM
BEST SERVICE SINCE 1997

[Click Here To Order Today](#)


A. Measure width of nose:



Full Face Mask Measurements

- Find measurement A. using top ruler.
- Find measurement B. using side ruler.
- Using both measurements, find your mask size in the chart below.

Anew® Size	A. Measurement	B. Measurement
Small	1" to 1 1/4"	3 1/4" to 3 1/2"
Regular	1 1/4" to 1 1/2"	3 1/2" to 3 3/4"
Large	1 1/2" & Up	3 3/4" & Up



B. Measure from bridge of nose to center of chin: 3 1/4 in"

3 1/2 in"

3 3/4 in"

NOTE: If your measurement falls between sizes on ANY mask, choose the SMALLER mask size.

101288 REV1